


Adande[®] Refrigeration



Operations Manual



Contents	Page
1 What is the Adande® System	3
2 Adande® Technology Explained	3
3 EC Declaration of Conformity	4
4 Storage of Product	5
5 Operating Adande® Temperature Settings	5
5.1 The Display Controls	5
5.2 Defrost	7
5.3 Drawer Alarm	7
5.4 Error Alarm	7
5.5 Temperature Alarm	7
5.6 Electrical Connection	8
5.7 Location and Stability	9
5.8 Servicing & Warranty	10
6 General Warning and safety Precautions	10
6.1 Electrical	10
6.2 Food	10
6.3 General	10
7 Unit Maintenance	11
8 Contact details	12

Welcome to Adande[®] Refrigeration

1 What is Adande[®]?

Adande[®] is a new method of cold storage developed as a series of insulated drawers, that each offer storage temperature flexibility in 1°C increments between –22°C and +15°C.

Each insulated drawer:-

- Provides stable temperature storage
- Is removable to act as temporary, cool and safe product storage.
- Gives full plan area access providing space efficient storage.
- Is easily cleaned or replaced.

2 Adande[®] Explained

Adande[®] uses standard technology and refrigeration parts but in a completely new and patented way.

A dedicated fridge engine supplies refrigerant to an evaporator coil assembly. The evaporator coil assembly then supplies cooling to the insulated drawer and is sized to maintain up to 40kg of product at any set point temperature, in the range of –22°C to +15°C.

Figure 1: Front view of Adande[®] Single Drawer unit



3 EC Declaration of Conformity

We declare that the following machinery complies with the essential health and safety requirements of:-

The Machinery Directive 2006/42/EC
The Low Voltage Directive 2006/95/EC
The Electromagnetic Compatibility Directive 2004/108/EC
The Pressure Equipment Directive 97/23/EC

Machinery Description: 1 Drawer Appliance for Chilled Storage.

Make: Adande®.

Type: Adande® Drawer Refrigeration Units

Manufactured by Adande® Refrigeration,
45 Pinbush Road, South Lowestoft Industrial Estate, Lowestoft, Suffolk NR33 7NL

The following transposed harmonised European Standards have been used:

EN ISO 12100 parts 1 & 2 Safety of Machinery – Basic concepts, general principles for design

EN ISO 13857 Safety of Machinery – Safety distances to prevent danger zones being reached by the upper and lower limbs.

EN ISO 13732-1: 2006 Ergonomics of the thermal environment -- Methods for the assessment of human responses to contact with surfaces -- Part 1: Hot surfaces

EN 1672-2 Food processing machinery – Basic concepts – Part 2 : Hygiene requirements

EN 61000-6-3:2001, Electromagnetic compatibility (EMC) - Part 6-3: Generic standards;

Emission standard for residential, commercial and light- industrial environments

EN 61000-6-1 Generic Immunity Standard; Residential commercial and light industrial environments.

EN 60335-2-24 The Safety of Household and Similar Electrical Appliances – Part 2 –24:

Particular Requirements for Refrigerating Appliances and Ice Makers.

The technical file for this machinery will be prepared on demand by :-

Name: Ian Wood

Position: Managing Director

Who signs on behalf of the manufacturer

ADANDE® REFRIGERATION

45 Pinbush Road

South Lowestoft Industrial Estate

Lowestoft

Suffolk

NR33 7NL

4 Storage of Product

For the unit to operate at full efficiency the drawer seal should be maintained in good condition. It is essential that the product is not stored above the “**MAX FILL LEVEL**” line as this can damage the seal and affect the operation of the unit.

The unit is capable of storing any food product. However, products which may give off acidic odours like vinegar, onions, etc should be suitably sealed. Adande® also recommends containers with liquid food products be stored with lids.

Ensure that the product is never stacked above the “**MAX FILL LEVEL**” Label in the drawer.

5 Operating Adande® - Temperature Settings

The Adande® temperature control system allows you to set and control the drawer within a temperature range of -22°C (-8°F) and +15°C (59°F).

Temperature accuracy in the drawer will be maintained within $\pm 2^{\circ}\text{C}$ of the set point.

5.1 The Display Controls

To adjust the temperature set point (figure 2) press and hold the “i” button, the drawer set point will then be displayed. While holding the “i” button increase or decrease temperature using the arrow buttons, on release of both buttons the new set point will be stored.




Figure 2: Adande® Display Control Panel

The controller can be locked to avoid accidental modification of drawer set point temperature.









	
<p>a) Press and immediately release “i” button to display ‘T1’</p>	<p>b) Press button “i” again to display ‘T2’</p>
	
<p>c) Press button “i” again to display ‘TH1’</p>	<p>d) Press button “i” again to display ‘TLO’</p>
	
<p>e) Press button “i” again to display ‘CND’</p>	<p>f) Press button “i” again to display ‘LOC’</p>
	
<p>g) Hold the “i” button to display either yes or no</p>	<p>h) Press either of the ▲ or ▼ buttons to change yes/no setting</p>

Figure 3: Locking Adande® Display Control Panel

5.2 Defrost

The refrigeration system automatically defrosts. If a manual defrost is required then press the manual defrost button on the control panel for 3 seconds.

5.3 Drawer Alarm

If the drawer is open for more than 10 minutes, the display in the control panel changes to “DO”.

When the alarm has been activated, the Adande® unit will alarm both visually and audibly.

To silence the audible alarm, press ANY button on the display, or close the drawer. The alarm light and flashing display will continue to show until the drawer has been fully closed.

NOTE: THERE IS NO COOLING TO THE DRAWER WHEN THE DRAWER IS OPEN.

5.4 Error Alarm

If display reads “E1” or “E2”, a temperature probe has failed, and an engineer should be called.

The Adande® unit will operate with a 15 minute on / 15 minute off cycle in the event of an “E1” failure. This will help to maintain the stored product at a safe temperature, but precise temperature control will be lost. “E2” will only affect defrosts, and these will be timed to maintain operation of the unit. An engineer should be called as soon as possible for either fault.

5.5 Temperature Alarm

Should “HI” appear on the display, the drawer temperature has exceeded its set point by 7°C. Product core temperature should be inspected. If the Adande® unit has recently been turned on, loaded with warm product or left open for a long period, this alarm could be displayed. If the temperature does not return to the set point temperature, an engineer should be called.

Should “LO” appear on the display, the drawer temperature has fallen below its set point by 7°C. Product core temperature should be inspected. If the Adande® unit drawer temperature set point has recently been increased, this alarm could be displayed. If the temperature does not return to the set point temperature, an engineer should be called.

5.6 Electrical Connection

The Adande® drawer unit should be connected to a 230V, single phase, 50 Hz, standard socket outlet supply. The unit is connected to the mains supply with a detachable supply lead, one end of which is fitted with a standard 13 amp 3 pin plug (fused at 13A). The other end of the supply lead, fitted with an appliance plug, is connected to the Adande® unit as shown in figure 3a below.




Figure 3a: Mains connection point

The unused socket on the right hand side in figure 3a can be used to provide a mains supply to additional Adande® units as shown in figure 3b below.




Figure 3b: Mains connection point

DO NOT REMOVE ACCESS PANELS WITH THE ELECTRICAL SUPPLY CONNECTED.

5.7 Location and Stability

It is important that the Adande® unit is installed and maintained on a flat, clean and **level surface** to ensure correct operation.

The room should be dry and sufficiently ventilated.

Optimum performance is obtained at ambient temperatures between +16°C (60°F) and +38°C (100°F).

Ensure that no obstructions are placed directly in front of the air outlet grille.

The Adande® drawer unit can be mounted on rubber feet, rollers or castors. When mounted on a castor base, the front two castors should have their brakes ON during normal use as in figure 4.



Figure 4: Lockable Castor

If the Adande® unit is mounted on two rollers at the rear of the unit, and rubber feet at the front, to move the unit, lift the front of the unit as in figure 5 and push or pull the unit into position.



Figure 5: Lifting unit to move when on rollers and feet

THE UNIT SHOULD BE UNLOADED BEFORE MOVING

5.8 Servicing & Warranty

Service personnel must be suitably trained in refrigeration and experienced in servicing Adande® units. Only used Adande® Approved and Registered Service Engineers which can be supplied on request.

Your Adande Unit should be regularly inspected and checked against the requirements of this Operations Manual. Failure to do so may invalidate the warranty. Your particular attention is drawn to the requirements of sections 6 and 7 of this document.

ACCESS PANELS MUST NOT BE REMOVED BY UNTRAINED PERSONNEL

Advice and help can be obtained to resolve any problems that may occur during operation or servicing, by contacting the Adande® technical support line, refer to Appendix 1 at the back of this manual.

6 General Warning and Safety Precautions

6.1 Electrical

- Untrained personnel should not remove any of the access panels.
- The access panels should not be removed with the electrical supply connected.
- To disconnect the electrical supply, remove the plug from the electrical socket.

6.2 Operational Use and Cleaning


- Use only a soft cloth, water or mild soap solutions to clean the unit.
- Do not use hard brushes or other items for cleaning.
- Remove any food which may have accidentally dropped from the food preparation surface into an open drawer or drawer runners.
- Do not leave drawers open for longer periods of time than necessary.
- If units are stacked, avoid opening more than one drawer at a time.
- Ensure products that give out acidic odours like vinegar, onions, etc. are sealed before storage in the unit.

6.3 General




- Do not exceed the maximum fill level or loading of 40kg per drawer.
- Do not sit, stand or apply additional downward pressure on an open drawer.
- Do not operate unit with any panels removed.
- Do not clean unit with any panels removed.
- Ensure unit is installed and maintained on a flat, clean and level surface.

- If mounted on a castor base, ensure brakes are applied to the front two castors to keep unit stationary at one location.
- The room in which the unit is kept should be dry and sufficiently ventilated.
- No obstructions should be placed directly in front of the condenser air outlet.
- Unit should be regularly inspected and checked against the requirements of this Operations Manual.

7.0 Unit Maintenance

	<p>The airflow through the Adande unit is designed to deposit grease and dirt on the outside surface of the insulated drawer and internal surfaces of the drawer housing.</p> <p>The insulated drawer must be removed from the unit to clean these surfaces.</p>
---	--

These dirt and grease deposits should be removed weekly using the following procedures:

<p>1. Clean the gasket on a weekly or daily basis if required with a solution of warm water and mild detergent.</p>	<p>2. The insulated drawer can be totally removed from the unit for deep cleaning. Clean the insulated drawer with an anti-bacterial cleanser.</p>
	
<p>NOTE: DO NOT USE SHARP UTENSILS</p>	
<p>3. Brush any loose dirt from the condenser.</p>	

4. Clean the steel surfaces with a polish cleaner.

NOTE:

DO NOT USE STEEL PADS, WIRE BRUSHES, SCRAPERS OR CHLORIDE CLEANERS TO CLEAN STAINLESS STEEL.



NOTE: DO NOT PRESSURE WASH EQUIPMENT AS DAMAGE TO ELECTRICAL COMPONENTS MAY RESULT.

8 Appendix 1: Contact Details

Stoddart Food Service Equipment
Service & Spare Parts - 1300 307 289
Sales - 1300 79 1954